

# VC Stripe Installation Guide

Passenger Side



Apply Decal from door edge forward  
to front wheel arch.



WE BUILD EXCITEMENT

1300 79 84 05 | [www.hdt.com.au](http://www.hdt.com.au)



# VC Stripe Installation Guide

Passenger Side



Apply Decal from Hinge edge of door  
back to rear wheel arch.

WE BUILD EXCITEMENT

1300 79 84 05 | [www.hdt.com.au](http://www.hdt.com.au)



# VC Stripe Installation Guide

Driver's Side



Peter Brock ATCC 1980 Wreath

For ease of application – apply additional masking tape over front of wreath decal so as not to mark clear background as you adhere to the vehicle.

Placement is 30mm in & 50mm up.



WE BUILD EXCITEMENT

1300 79 84 05 | [www.hdt.com.au](http://www.hdt.com.au)



# VC Stripe Installation Guide

Rear of Vehicle



Rear Boot Lid Decal

Placement is 48mm in & 30mm up.

WE BUILD EXCITEMENT

1300 79 84 05 | [www.hdt.com.au](http://www.hdt.com.au)

